

Тросики дистанционного управления камерой SlideKamera к мотору SlideKamera HKN-2

HKN-WS-1	HKN-WS-2			HKN-WS-3
Canon EOS 30D Canon EOS 40D Canon EOS 50D Canon EOS 5D Canon EOS 5D mk II Canon EOS 5D mk III Canon EOS 6D Canon EOS 7D Canon EOS D30 Canon EOS D60 Kodak DSC-530	Canon Digital Rebel Canon EOS 1000D Canon EOS 100D Canon EOS 1100D Canon EOS 300D Canon EOS 350D Canon EOS 400D Canon EOS 450D Canon EOS 500D Canon EOS 550D Canon EOS 600D Canon EOS 60D Canon EOS 60Da Canon EOS 650D Canon EOS 700D Canon EOS 70D Canon Kiss Digital Canon Kiss F Digital Canon Kiss N Canon Kiss X2 Canon Kiss X3 Canon Kiss X4 Canon Kiss X5 Canon Kiss X50 Canon Kiss X6 Canon PowerShot G1 X Canon PowerShot G10 Canon PowerShot G11 Canon PowerShot G12 Canon PowerShot G15	Canon PowerShot SX50 HS Canon Rebel SL1 Canon Rebel T1i Canon Rebel T2i Canon Rebel T3 Canon Rebel T3i Canon Rebel T4i Canon Rebel T5i Canon Rebel XS Canon Rebel XSi Canon Rebel XT Canon Rebel XTi Contax 645 Contax N Contax N Digital Contax N1 Contax NX FujiFilm X-E1 Hasselblad H Hasselblad H3D Hasselblad H4D-200MS Hasselblad H4D-31 Hasselblad H4D-40 Hasselblad H4D-50 Hasselblad H4D-50MS Hasselblad H4D-60 Pentax 645D Pentaxist D Pentax ist DL Pentax ist DL2 Pentax ist DS	Pentax ist DS2 Pentax K-30 Pentax K-5 Pentax K-5 II Pentax K-5 IIs Pentax K-50 Pentax K-500 Pentax K-7 Pentax K-m Pentax K10 Grand Prix Pentax K100D Pentax K100D Super Pentax K10D Pentax K1 10D Pentax K200D Pentax K20D Pentax MZ-6 Pentax MZ-L Pentax ZX-L Samsung GX-1L Samsung GX-1S Samsung GX-20 Samsung NX-10 Samsung NX-100 Samsung NX-11 Samsung NX-5 Sigma SD1 Sigma SD1 Merrill Sigma SD15	FujiFilm S3 Pro FujiFilm S5 Pro Kodak DCS Pro 14n Nikon D1 Nikon D1H Nikon D1X Nikon D2 Nikon D200 Nikon D2H Nikon D2HS Nikon D2X Nikon D2XS Nikon D3 Nikon D300 Nikon D300S Nikon D3s Nikon D3X Nikon D4 Nikon D700 Nikon D800 Nikon D800 E
HKN-WS-4	HKN-WS-5		HKN-WS-6	
Nikon D3100 Nikon D3200 Nikon D5000 Nikon D5100 Nikon D5200	Nikon D60 Nikon D7000 Nikon D7100 Nikon D90	Nikon D70S Nikon D80	Leica DigiLux 2 Leica DigiLux 3 Leica V Lux 1 Leica V Lux 2 Leica V Lux 3 Panasonic FT2 Panasonic FZ100 Panasonic FZ15 Panasonic FZ150 Panasonic FZ20 Panasonic FZ200 Panasonic FZ30 Panasonic FZ50 Panasonic G1	Panasonic G10 Panasonic G2 Panasonic G3 Panasonic G5 Panasonic GF1 Panasonic GH1 Panasonic GH2 Panasonic GH3 Panasonic GX1 Panasonic L1 Panasonic L10 Panasonic LC1 Panasonic TS2